KitchenAid® OVEN PARTS

For Models:KEMC308KBL02, KEMC308KWH02, KEMC308KBT02, KEMC308KSS02
(Black) (White) (Biscuit) (Stainless Steel)

30" BUILT−IN ELECTRIC
DOUBLE OVEN
THERMAL CONVECTION LOWER
MICROWAVE CONVECTION UPPER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models:KEMC308KBL02, KEMC308KWH02, KEMC308KBT02, KEMC308KSS02
(Black) (White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8300653	Installation Instructions
	4456573	Use & Care Guide (Oven)
	8300890	Use & Care Guide (Microwave)
	4450786	Cooking Guide (Lable)
	8302001	Tech Sheet (Oven)
	4449264	Easy Set Guide
	3191638	Safer Cooking Tips
	4451052	Easy Use Guide (Microwave)
3		Hinge Reciever
	4455605	Left Hand
	4455606	Right Hand
4	4448520	Bumper, Door
5		Trim, Side
	4455430	RH Black
	4455434	RH Biscuit
	4455432	RH White
	4452083	RH S. Steel
	4455431	LH Black
	4455435	LH Biscuit
	4455433	LH White
	4452084	LH S. Steel
		Screw
	8281236	Black
	694091	White
6	4452490	Spacer, Foam
7	4455865	Top Chassis
	4449809	Screw
9	4452158	Tube, Vent
	3196176	Screw
10	4452163	Lens, Light
11	4448972	Oven Light Assy
	4449748	Screw
12	4452164	Bulb, Light
13	9752759	Relay
	3400832	Screw
14	9759060	Frame, Front
	4449040	Screw
	4450118	Nut
15	4455382	Gasket, Door
19	4451478	Support, Insulation
20	4451605	Cap, Spacer
21		Rail, Side
	4450583	Right Side
	4450584	Left Side
	4448444	Grommet
	4449154	Screw
25	4455641	Side, Chassis (R.H. & L.H.)
	4449809	Screw
26	4452234	Back, Chassis
	4449809	Screw
27		Liner, Oven (Not serviceable)
29	4455636	Sensor
	4449154	Screw
30	4449845	Bracket, Support
	4449809	Screw
33	9760677	Deflector, Vent
34	8302592	Vent, Center
	4450038	Screw
	3400832	Screw
43	9759713	Base, Chassis
	4449809	Screw
49	4448933	Retainer, Gasket
	4449154	Screw
50	4451747	Cover, Back
	4449809	Screw
51		Trim, Bottom
	4455443	Black
	4455445	White
	4455447	Biscuit
	4455147	Stainless Steel
	3400805	Screw
	4452152	Bracket, Vent Mounting
52	4451756	Chassis, Back
53	4452492	Insulation, Convection Top
54	4452491	Insulation, Convection Grill

FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

4449316	Insulation, Wrap
4450365	Insulation, Back
4452337	Insulation, Bottom Vent

CONTROL PANEL PARTS

For Models:KEMC308KBL02, KEMC308KWH02, KEMC308KBT02, KEMC308KSS02
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1		Panel. Control
	4452604	Black
	4452605	White
	4452974	Biscuit
	4451791	Stainless Steel
2		Switch Membrane
	8302670	Black
	8302674	White
	8302672	Biscuit
	8302660	Stainless Steel
	3400832	Screw
5	4452260	Spacer, Foam
7	8302346	Assy, Control
	4449745	Screw
	3400832	Screw

OVEN DOOR PARTS

For Models:KEMC308KBL02, KEMC308KWH02, KEMC308KBT02, KEMC308KSS02
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4457127	Door Liner
2		Hinge, Door
	8300575	Rt Side (clear)
	8300576	Lft Side (clear)
	4449743	Screw
3	4449259	Glass, Inner
4	4451722	Insulation, Door
5	8300778	Retainer, Glass
	4449809	Screw
7	9759225	Glass, Inner
12		Door Glass, Assy
	4455391	Black
	4455390	White
	4455395	Biscuit
	4452316	Stainless Steel
13		Door Handle
	4452502	Black
	4452503	White
	4452871	Biscuit
	4452088	Stainless Steel
14		Bracket, Handle
	4455803	Right Hand
	4455804	Left Hand
	3196184	Screw
15	9759229	Bracket(2nd Glass)
19	4457103	Shield, Heat
	4449809	Screw
20	4457132	Retainer, Glass
	4449809	Screw
22	4457114	Shield, Heat(Btm)
23		Retainer, Glass−Clip
	4450863	Black
	4450864	White
	4452119	Almond
	4451432	Stainless Steel
24	9759228	Glass, Inner
25	4452326	Seal, Pano
26	9759230	Bracket(3rd Glass)

LATCH PARTS

For Models:KEMC308KBL02, KEMC308KWH02, KEMC308KBT02, KEMC308KSS02
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent−Top
3	8300791	Bracket, Combo Chassis
5	4455177	Elbow, Vent−Bottom
6	4451758	Seal, Foam
9	4450408	Baffle, Rear
	4449154	Screw
10	9759481	Latch, Motorized
16	4452003	Blower
	4449809	Screw
19	4449906	EXT Filler
	4455191	Plate, Service

IMPORTANT
PRODUCT SAFETY INFORMATION

ADVISE CONSUMERS OF AN ELECTROCUTION HAZARD WITH DO – IT – YOURSELF REPAIRS OF MICROWAVE OVENS.

The U.S. Consumer Product Saftey Commission warns against do – it – yourself repairs of microwave ovens. Microwave ovens use high voltage which makes it particularly hazardous for consumers to remove the cover and touch electrical parts.

STRONGLY RECOMMEND THAT CONSUMERS HAVE PROFESSIONALS REPAIR MICROWAVE OVENS.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models:KEMC308KBL02, KEMC308KWH02, KEMC308KBT02, KEMC308KSS02
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
2	4456104	Element, Broil
	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	3181534	Rack, Roasting
6	4448717	Rack, Oven
7	4452155	Element, Bake
8	4448881	Nut, Hex
9	4451583	Convection, Motor
	4449154	Screw
10	4452226	Blade, Fan
11	4448882	Washer, Lock
12	4452227	Nut
13	4451355	Jack, Meat Probe
14	4448948	Probe, Meat
15	4455037	Tray, Bake
17	4450039	Cover, Bake Tray
	4449809	Screw
20	4452157	Element, Convection
	4449154	Screw
21	4448418	Cover, Fan
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS

For Models:KEMC308KBL02, KEMC308KWH02, KEMC308KBT02, KEMC308KSS02
(Black) (White) (Biscuit) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS

For Models:KEMC308KBL02, KEMC308KWH02, KEMC308KBT02, KEMC308KSS02
(Black) (White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	4375437	Bracket, Capacitor
3	4375252	Rubber Ring
4	4375038	Screw
5	4375314	Air Duct, Magnetron
6	4375253	Support, Tube
7	4375421	Plug, Ceramic
8	4375255	Bushing
9	4375256	Reflector
10	4375257	Chamber, Reflector
12	4375450	Duct, Inlet
13	4375316	Insulation, Switch
14	4375322	Fan Wheel
15	4375317	Duct, Air
16	4375415	Block, Slide
17	4375248	Cover Plate, Upper
18	4375251	Screw
19	4375318	Lens, Lamp
20	4375319	Spring
21	4375320	Reflector
23	4375276	Rack
24	4393536	Crisp Plate
25	4375436	Capacitor
26	4375424	Magnetron
27	4375321	Fuse
28	4375231	Block, Fuse
29	4375278	Motor, Blower
30	4375279	Thermostat
31	4375423	Thermostat
32	4375281	Thermostat
33	4375408	Q Tube Assembly
34	4375438	Transformer
35	4375406	Ring, Turntable
36	4375407	Shaft, Turntable
39		Bracket, Hinge
	4375412	Left
	4375413	Right
42	4375331	Plate, Grill
43	4375332	Bracket
44	4375441	Fan Cap
46		Switch Holder
	4375412	Left
	4375413	Right
47	4375258	Nut
48		Insulation
	4375409	Left Side
	4375410	Right Side
49	4375411	Plate, Side
		Bottom
50	4375425	Valve
51	4375428	Screw To Valve
52	4375427	Thermoactuator
53	4375426	Air Bleed
54	4375439	Shield, Heat
		Right
55	4375422	Sensor, Temp.
56	4375420	Insulation
57	4375419	Duct, Heater
58	4375416	Washer
59	4375417	Element, Heater
60	4375418	Fan
61	4375429	Motor, Fan
62		Left−Threaded Nut
		Serviced With
		Motor Item 61
63	4375430	Thermostat
64	4375431	Shield, Heat
65	4375432	Insulation
66	4375433	Chamber, Heat
		Cabinet
67	4375437	Isolation Plate
68	4375338	Cover Plate
71		Side Plate
	4375341	Left
	4375342	Right
72	4455915	Turntable
73	4375346	Switch
74	4375347	Motor, Turntable
75	4375348	Lamp
76	4375349	Rectifier
77	4452220	Rack, Convection

MICROWAVE COMPARTMENT PARTS

For Models:KEMC308KBL02, KEMC308KWH02, KEMC308KBT02, KEMC308KSS02
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
5		Support Rails
	4452551	Right Side
	4452552	Left Side
	4449809	Screw
11	4452548	Rear Channel
	4449809	Screw
	4449154	Screw

TOP VENTING PARTS

For Models:KEMC308KBL02, KEMC308KWH02, KEMC308KBT02, KEMC308KSS02
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4450378	Cover, Top
	4449809	Screw
2	4448935	Baffle, Blower
	1180485	Screw
3	4450920	Blower
	4449809	Screw
4	4451789	Plate, Mounting
5	9760588	Transformer, (Lights)
	4449809	Screw
6	4451634	Exhaust Duct
7	4450027	Bracket, Duct
8	4449964	Grommet
	4449809	Screw
	112432	Nut
9	4454949	Holder, Fuse
	4449154	Screw
10	4454976	Fuse
11	4449868	Block, Terminal
	3400080	Screw
12	4452559	Side, Combo
	4449809	Screw
13	4456145	Vent, (Control Panel)
	4450038	Screw
14		Side, Control Top
	4451597	Right
	4451598	Left
	4449809	Screw
15	4452244	Back, Control
	4449809	Screw
16	4450551	Cover, Top Rear
	4449809	Screw
17	4448664	Clamp
	4449809	Screw
18	4452367	Cover, Top Front
	4449809	Screw
19	4455038	Transformer, Control
20	4452247	Cover, Plate
	4449809	Screw
21	4451934	Suppressor

MICROWAVE DOOR PARTS

For Models:KEMC308KBL02, KEMC308KWH02, KEMC308KBT02, KEMC308KSS02
(Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	4448937	Glass, Middle
2	8303556	Frame, Door
	4450038	Screw
4		Bracket, Mounting
	4449141	Right Side
	4449142	Left Side
	4449809	Screw
5		Filler, Side
	4449083	Right Side
	4449086	Left Side
	4449809	Screw

Illus. No.	Part No.	DESCRIPTION
6		Handle, Door
	4452502	Black
	4452503	White
	4452871	Biscuit
	4452088	Stainless Steel
7		Glass, Outer
	4452211	Black
	4452789	White
	4452995	Biscuit
	4452259	Stainless (Assy)
9	4452331	Bracket, Handle
	3196184	Screw

Illus. No.	Part No.	DESCRIPTION
10		Retainer, Glass−Clip
	4450863	Black
	4450864	White
	4451432	Stainless Steel
	4452119	Biscuit
11	4375339	Door, Plate
12	4375414	Frame, Inner
13	4375330	Strap, Door
14	4375313	Screw
15		Hinge, Door
	4375323	Left
16	4451009	Spring,Torsion RH
17	4452395	Spring,TorsionLH
	4375324	Right

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models:KEMC308KBL02, KEMC308KWH02, KEMC308KBT02, KEMC308KSS02
(Black) (White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION

PAINT, TOUCH−UP (1/2oz.)

72017	White
261869	Cord Brown
72032	Black

PAINT, SPRAY

350930	White
261900	Citrine White
830864	Black

ADHESIVE

591014	Adhesive Loctite (1/3 oz.)
482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION

SPLICING WIRES−−25FT. LENGTH

242828	Wire (12 Ga. 150 c Black)
242820	Wire (14 Ga. 150 c Black)
242821	Wire (14 Ga. 150 c Blue)
242822	Wire (14 Ga. 150 c Brown)
242830	Wire (14 Ga. 200 c Brown)
242823	Wire (14 Ga. 150 c Green)
242824	Wire (14 Ga. 150 c Orange)
242829	Wire (12 Ga. 150 c Red)
242825	Wire (14 Ga. 150 c Red)
242831	Wire (14 Ga. 200 c Red)
242826	Wire (14 Ga. 150 c White)
242827	Wire (14 Ga. 150 c Yellow)
242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION

FOLLOWING PARTS NOT ILLUSTRATED

4378944	Filler Kit (BL)
4378945	Filler Kit (WH)
4378946	Filler Kit (AL)

WIRING HARNESS PARTS

8301909	Harness, Latch
4452400	Lead, Ground
4449809	Screw
8301923	Harness, Main
4450831	Ground (M/W)
4450800	Screw, Ground
4449809	Screw
4450950	Conduit, Combo
313438	Clip, Harness
4452222	Spacer, Harness
4454835	Tie, Cable

Miscellaneous

4448950	Screw, Install (4)
814381	Hinge Pin Kit